

INSTREAMER



Instreamer

Network audio encoder for
commercial, industrial and
security applications



User Manual

Firmware V2.06

Released 22. Mar. 2007

Supports:

- INSTREAMER (legacy)
- INSTREAMER 100



Table of Contents

1	Introduction.....	9
1.1	About the “Instreamer” firmware.....	9
1.2	Features.....	10
1.3	Installing the device.....	10
1.4	Additional documents.....	11
1.5	Preloaded Firmware.....	11
1.6	About this manual.....	11
	Links to chapters.....	11
	Links to the Dictionary.....	11
	Bookmarks pane in Adobe Acrobat.....	11
	Chapter overview.....	12
2	Device Status and Control.....	13
2.1	Status and Control.....	14
	Refresh.....	14
	Status.....	14
	Input peak value.....	14
	SENDING.....	14
	CTS IN (RS-232).....	14
	RTS OUT (RS-232).....	14
3	Device Configuration.....	15
3.1	Network settings.....	16
	IP Address.....	16
	Netmask.....	17
	Gateway IP Address.....	17
	Use SonicIP.....	18
3.2	Audio settings.....	19
	Input source.....	19
	Channel Mode.....	19
	Encoding & Frequency.....	19
	Encoding Quality.....	20
	Advanced Encoder Settings.....	21

A/D amplifier gain.....	21
MP3 Frame CRC.....	21
MP3 Bitreservoir Mode.....	21
MP3 Channel Mode Extension.....	21
MP3 Copyright Protection.....	21
MP3 Stream Type.....	22
MP3 Emphasis.....	22
3.3 Streaming settings.....	23
Own Name.....	24
Streaming mode.....	24
Trigger level.....	24
Pre Trigger Start.....	24
Post Trigger Play.....	24
Buffer Underrun Mode (TCP).....	25
Streaming Strategy.....	25
UDP Tx Source Port.....	25
Sync Port.....	25
Radio Path.....	25
icy-url / SIP user.....	26
icy-genre.....	26
Shoutcast stream.....	26
Stream to.....	26
“Stream to” Considerations.....	26
Stream to “Disabled” entry.....	27
Stream to “Internet Radio” entry.....	27
Stream to “RTP” entry.....	28
Stream to “BRTP” entry.....	28
Stream to “SIP” entry.....	28
Stream to “Raw UDP” entry.....	28
Stream to “Raw TCP” entry.....	28
Stream to “Icecast source” entry.....	29
Stream to “Icecast / ID3 source” entry.....	29
Stream to “Shoutcast source” entry.....	29
SNMP settings.....	29
Trap Target IP Address.....	29
Low Audio Level.....	30
High Audio Level.....	30
Trap Repeat.....	30
Silence Timeout.....	30

3.4	I/O Settings.....	31
	CTS close command.....	31
	CTS open command.....	31
	Commands.....	31
3.5	Control settings.....	32
	UDP command port.....	32
	TCP command port.....	32
	Web server port.....	32
3.6	Serial settings.....	33
	Baud rate.....	33
	Data bits.....	33
	Parity.....	33
	Stop bits.....	33
	Flow control.....	33
	Local port.....	34
	Destination IP.....	34
	Destination port.....	34
3.7	Security settings.....	35
	Telnet / Serial configuration.....	35
	Save configuration.....	35
	Save configuration password usage.....	35
	View configuration.....	36
	View configuration password usage.....	36
	Control / Command.....	37
	Level 4 to 6 (User).....	37
	Ice/Shoutcast.....	37
	Listening.....	37
	SNMP Community RWrite.....	38
	SNMP Community Read.....	38
4	Reverting to factory defaults.....	39
	Hard default settings.....	40
5	Rebooting the device.....	41
6	Updating the device.....	42
6.1	Downloading the latest firmware.....	42
6.2	Serial Rescue.....	43

6.3	Web Update.....	43
7	Dictionary.....	49
8	Legal Information.....	51

I Introduction

I.1 About the “Instreamer” firmware

The “Instreamer” firmware is designed to serve as a versatile, network-enabled analog and digital audio-to-Ethernet converter for commercial audio distribution.

The “Instreamer” firmware converts audio from any analog or digital device into G.711 (8 bit), PCM (16 bit) or high-quality MP3 streams. The audio is encoded in real-time, and the generated audio stream can be distributed, via an IP-based network or the Internet, to one or more receivers or Shoutcast / Icecast-servers.

Barix devices running the “Instreamer” firmware can be easily managed via a web browser interface using PCs, web pads, PDAs or other web-enabled devices. SNMP remote monitoring capabilities allow for building a manageable distributed audio network. With serial and Ethernet control APIs, open IP-standards, and the standard encoding formats, the device can also be integrated with other components, controlled by automation systems, or used with Barix Exstreamers to create more flexible, more cost-effective distributed audio systems.

The built-in serial interface allows data to be relayed to another Barix device, a PC or a server using the “Serial Gateway” functionality of the “Instreamer” firmware.

With an optional stick-on transmitter, additional IR-enabled devices can be remote controlled via the network connection, enabling users to control their audio sources without being in the same location as the device.

1.2 Features

- Generates MP3 streams at adjustable bit rates (VBR) from analog or digital (optical/coaxial S/P DIF) sources
- Generates G.711 (aLaw/uLaw) streams at 8 or 24 kHz sample rate from an analog source
- Generates PCM (16 bit) streams at 8 or 24 kHz sample rate from an analog source
- Supported stream connections: HTTP, BRTP, RTP, SIP, Raw UDP, Raw TCP, Icecast and Icecast ID3 source, Shoutcast source
- Supports stream authentication (HTTP, Shoutcast, Icecast)
- 10/100 Mbit Ethernet connection supports automatic network configuration (BOOTP, [DHCP](#), AutoIP and [IPzator](#)) as well as manual static [IP](#) configuration
- Features [SonicIP](#)® announcing the [IP](#) address on power up over the audio outputs
- Control and configuration using a standard web browser
- Remote monitoring using SNMP
- Remote controllable using HTTP, TCP and UDP
- Supports IR remote control command relaying (Network to IR out)
- Supports Serial Port relaying (Serial gateway over Network)

1.3 Installing the device

For the installation of the Barix Instreamer 100 or the legacy Barix Instreamer please refer to the corresponding “Quick Install Guide”.

A printed version is included in the box and can also be downloaded from our site www.barix.com.

1.4 Additional documents

Technical specifications can be found in the corresponding product sheet which can be downloaded from our site www.barix.com.

For detailed technical information about the CGI application programming interface (API) please download the “Instreamer Technical Documentation” from our website.

1.5 Preloaded Firmware

Barix preloads all Instreamer family devices with the “Instreamer” firmware version.

Before continuing with this manual make sure that the firmware version is up to date and corresponds with this manual. Please proceed to chapter [6 Updating the device](#) in order to do so.

1.6 About this manual

Links to chapters

References to chapters (e.g. [X Chapter name](#)) are red and underlined and serve as direct links when viewed in Adobe Acrobat Viewer. Click on the link to jump to the referenced chapter, click on the left arrow icon to jump back to where you came from.

Links to the Dictionary

Some technical terms (e.g. [DHCP](#)) are underlined and red. Click on them to jump to the dictionary at the end of this manual, click on the left arrow icon to jump back.

Bookmarks pane in Adobe Acrobat

The complete “Table of Contents” is available in Adobe

Acrobat Viewer. Click on the “Bookmarks” pane tab on the left side of Adobe Acrobat Viewer to open it. Click on any bookmark to directly jump to the corresponding part of the manual.

Chapter overview

This manual is divided into the following chapters:

- Device Configuration (explaining all configuration parameters)
- Updating the Firmware (explaining how to update or how to change from “standard firmware”)
- Step by step “How To” (explaining configuration for external services and devices)
- IR Remote control (explaining the functionality of the Barix IR Remote control)
- Advanced User section (explaining configuration via Serial cable and reference to the CGI API)
- Dictionary (explaining technical names and expressions used in this manual)

2 Device Status and Control


To view the current status and control it using the Web interface you will need:

- the **IP** address announced over the audio outputs (see the Quick Install Guide)
- a standard web browser

Open your web browser and type in the **IP** address of the Barix device in the URL field and hit the “Enter” key.

- Example: “192.168.0.12”

You will see the following window content:



The top frame shows the logos “INSTREAMER” and “BARIX”. A click on either logo will bring you to the Barix homepage.

Help information will show up in the right, grey frame of the browser window.

The left white frame shows current status information and permits the control of the streaming status, the simulation of the CTS input signal and the control of the RTS output. For details see the section below.

2.1 Status and Control

Refresh

The status frame page is refreshed every couple of seconds. To refresh it on demand click the reload button left of the word "Status".

Status

Shows the current status "INACTIVE" or "SENDING".

Input peak value

The number [0..65535] shows the peak value of the encoder input (Line or Microphone) for the left and right channel separately.

SENDING

The LED next to SENDING has the following meaning: GREY for not sending, GREEN for sending
When the device is set to "send on CTS" then the following two links will appear:
Click the "SEND" link to start sending the stream.
Click the "STOP" link to stop sending.

CTS IN (RS-232)

Click the "SET" link to simulate CTS being activated.
Click the "CLR" link to simulate CTS being deactivated.
The LED next to "CTS IN" shows the status of the physical CTS signal (the simulation is not shown!) and has the following meaning:
GREY for inactivated, GREEN for activated

RTS OUT (RS-232)

Click the "SET" link to activate the RTS output.
Click the "CLR" link to deactivate the RTS output.
The LED next to "RTS OUT" has the following meaning:
GREY for inactivated, GREEN for activated

3 Device Configuration


You can adjust network settings, streaming destinations, monitoring settings and more with the Web interface. To enter the configuration mode you will need:

- the **IP** address announced over the audio outputs (see the [Quick Install Guide](#))
- a standard web browser

Open your web browser and type in the IP address of the Barix device in the URL field and hit the “Enter” key.

- Example: “192.168.0.10”

You will see the following window content:



The top frame shows the logos “INSTREAMER” and “BARIX”. A click on either logo will bring you to the Barix homepage.

The left white frame shows current status information and permits the control of the streaming status, the simulation of the CTS input signal and the control of the RTS output.

Help information will show up in the right, grey frame of the browser window.

To obtain the configuration pages click the **CONFIGURATION** button below the Instreamer graphic.

3.1 Network settings

This chapter explains how to adjust the network settings of the Barix device.

SETTINGS						
NETWORK	AUDIO	STREAMING	VO	CONTROL	SERIAL	SECURITY
IP Address	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>		
Netmask	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>		
Gateway IP Address	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>		
Use SonicIP®	<input checked="" type="radio"/> Yes <input type="radio"/> No					
<input type="button" value="Apply"/> <input type="button" value="Cancel"/>						

We recommend that you set a **Static IP** address. With a static (permanent) **IP** address the device does not have to get a new IP address at power on or reboot.

IP Address

Enter the 4 values of the desired static **IP** address e.g.:

- “192.168.0.12” for an internal LAN

Attention: Make sure that you enter a free IP address. The device will check this and will not be available until the device using the same IP is disconnected or switched off. The command **Ping** can be used to ensure that a specific IP address is unused (i.e. No reply).

The automatic discovery functions are not executed if a **Static IP** address is set.

Enter 4 zeroes to enable it:

- “0.0.0.0” for automatic discovery (Discovery order: BOOTP, **DHCP**, **IPzator**, AutoIP)

To enable automatic discovery but disable certain IP discovery functions set all but the third value to zero. For each function you want to disable add the value from the table below:

- "0.0.1.0" to disable AutoIP
- "0.0.2.0" to disable [DHCP](#)
- "0.0.4.0" to disable BOOTP
- "0.0.8.0" to disable [IPzator](#)

Examples:

- "0.0.3.0" disables AutoIP and [DHCP](#)
- "0.0.11.0" disables all but BOOTP

Attention: "0.0.15.0" disables all discovery functions which locks you out unless you reset the device to factory defaults by pressing the reset button for about 10 seconds.

Netmask

Enter the 4 values of the desired [Netmask](#) e.g.:

- "0.0.0.0" for a default Netmask depending on the IP Address used
- "255.255.255.0" for a C class network

Note: Try first the Netmask your PC is set to or ask your Network Administrator.

Gateway IP Address

A correct setting of the Gateway IP address is needed to stream to the Internet or to destinations outside your local network (LAN).

Enter the 4 values of the desired Gateway IP address e.g.:

- "0.0.0.0" for no Gateway or automatic discovery
- "192.168.0.1" for a Gateway in a LAN

Note: If you have set the devices IP address to automatic discovery and your server or router has issued an IP address then most probably it also has supplied a valid Gateway address, "0.0.0.0" will then work fine.

If you have set a [Static IP](#) address then you will need to

configure a valid Gateway address manually. Try first the same Gateway IP address your PC is set to. If it doesn't work then ask your Network Administrator for a correct Gateway IP address.

Use SonicIP

If “Use [SonicIP](#)” is set to yes, the device will announce its IP address over the audio output during start up.

3.2 Audio settings

This chapter explains how to adjust the audio input and output settings of the Barix device.

SETTINGS

NETWORK	AUDIO	STREAMING	I/O	CONTROL	SERIAL	SECURITY
----------------	--------------	------------------	------------	----------------	---------------	-----------------

Input source Line SPDIF optical SPDIF coaxial

Channel Mode stereo mono

Encoding+Frequency ▾

MPEG Encoding quality ▾

Advanced Encoder Settings

A/D amplifier gain dB

MP3 Frame CRC enable disable

MP3 Bitreservoir Mode used kept empty

MP3 Channel Mode Extension enable disable MS-Stereo encoding

MP3 Copyright Protection enable disable

MP3 Stream Type copy original

MP3 Emphasis ▾

Input source

Choose the desired audio input source. “Line” selects the stereo line inputs (white and red RCA sockets), “S/P DIF optical” the optical socket and “S/P DIF coaxial” the digital input (black RCA socket).

Channel Mode

Select between “stereo” and “mono” input mode. When “mono” is selected only the left channel will be encoded. See also the parameter “MP3 Channel Mode Extension” further below.

Encoding & Frequency

Choose between six different MP3, four G.711 and two PCM encoding settings. From “MPEG1 / 48 kHz” down to “MPEG2 / 16 kHz” as well as G.711 (aLaw or uLaw) or

PCM (both in 8 or 24 kHz). The bit rate used for G.711 and for PCM is displayed in kbit/sec. in the table below.

Encoding / Sampling freq.	8 kHz	24 kHz
G.711 8bit (uLaw or aLaw)	64	192
PCM 16bit	128	384

For MP3 average bit rate see the next section.

Note: In case of S/PDIF input, MPEG1 is used and the sampling frequency is auto detected (32, 44.1 or 48 kHz).

Encoding Quality

This parameter applies only when MPEG encoding is selected in the previous parameter. Choose between "0 lowest" and "7 highest" in steps of 1. The encoder quality table below shows the average bit rate in kilobits per second for the quality settings and sampling frequencies in kHz using mono input with MS-Stereo encoding disabled.

Encod./Quality	0	1	2	3	4	5	6	7
MPEG1 48kHz	72	76	80	88	96	112	144	160
MPEG1 44.1kHz	65	68	73	80	90	105	125	140
MPEG1 32kHz	52	56	64	72	80	96	112	136
MPEG2 24kHz	38	44	48	52	60	80	96	112
MPEG2 22.05kHz	35	38	40	45	50	60	75	90
MPEG2 16kHz	28	30	34	40	44	48	56	64

The encoder quality table below shows the average bit rate in kbit/s (kilobits per second) for the quality settings and sampling frequencies in kHz using stereo inputs.

Encod./Quality	0	1	2	3	4	5	6	7
MPEG1 48kHz	88	96	104	120	144	160	176	192
MPEG2 16kHz	35	38	44	48	56	64	80	96

The above table shows only the average bit rates for 16

kHz and for 48 kHz. As the “stereo” adds about 20 to 30 percent when compared to “mono” other sampling frequencies can be calculated using the previous “mono” table.

Advanced Encoder Settings

These following settings are for advanced users only. Detailed information about the Encoder Settings can be found in the Micronas MAS3587 MP3 encoder data sheet.

A/D amplifier gain

Choose the desired gain (“-3” up to “19.5” dB) for the line input A/D amplifier.

Note: The line input sensitivity has changed from 2 Volts peak to peak on legacy devices to 4 Volts peak to peak on the new “Instreamer 100” (less sensitive).

MP3 Frame CRC

If set to “enable”, the encoder will include the CRC-16 to each MP3 frame.

MP3 Bitreservoir Mode

The “Bitreservoir” is used to compensate the differences between the predefined frame sizes. If set to “used”, the encoder will use the bitreservoir. Leave the setting to “kept empty” if you use RTP streaming or need low latency on the transmission.

MP3 Channel Mode Extension

“Enable” or “disable” the MS-Stereo encoding (for stereo only). When set to “disable MS-Stereo encoding” only mono will be encoded and therefore the bandwidth used is minimized.

MP3 Copyright Protection

“Enable” or “disable” the copyright protection bit in the MP3 stream.

MP3 Stream Type

Select between a “copy” or an “original” in order to set the appropriate bit in the MP3 stream.

MP3 Emphasis

Select emphasis “none”, “50/15 us” or “CCITT J.17”.

3.3 Streaming settings

These settings adjust the streaming mode, parameters and destinations.

SETTINGS

NETWORK	AUDIO	STREAMING	I/O	CONTROL	SERIAL	SECURITY
---------	-------	-----------	-----	---------	--------	----------

Own Name

Streaming mode ▼

Trigger Level only for mode "send on Level"

Pre Trigger Start msec

Post Trigger Play msec

Buffer Underrun Mode (TCP) ▼

Stream Packet Strategy ▼

UDP Tx Source Port

Sync Port

Radio Path

icy-url / SIP user

icy-genre

Shoutcast stream ▼

Stream to

#	Conn. type	IP #	#	#	#	#	Port #
1	<input type="text" value="B RTP"/> ▼	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	: 4040
2	<input type="text" value="RTP"/> ▼	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	: 4040
3	<input type="text" value="Raw UDP"/> ▼	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	: 0
4	<input type="text" value="Raw TCP"/> ▼	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	: 2020
5	<input type="text" value="Icecast source"/> ▼	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	: 0
6	<input type="text" value="Icecast / ID3 source"/> ▼	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	: 0
7	<input type="text" value="Shoutcast source"/> ▼	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	: 0
8	<input type="text" value="Internet Radio"/> ▼	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	: 0

SNMP

Trap Target IP Address . . .

Low Audio Level **Left** **Right**

High Audio Level **Left** **Right**

Trap Repeat **Left** sec **Right** sec

Silence Timeout **Left** sec **Right** sec

Own Name

You can enter the name of the Barix Instreamer here. This name will be returned when using the DISCOVER command (see technical documentation) and will be used for the SYNC function in the Barix Exstreamer (see Barix Exstreamer User Manual).

Streaming mode

Streaming is started depending on the selected operating mode:

- “send always” will stream always
- “send on CTS” will stream if the SEND button (command) is pressed or CTS (Pin 8 Serial connector) is connected to a positive supply (9VDC, Pin 4 Serial connector)
- “send on Level” will stream if the incoming audio signal is above the Trigger level (see section below)

Trigger level

The “Trigger level” is only used when Streaming mode is set “send on Level”.

Select a value between 0 and 32767.

Open the Device status page and look for the Input peak value to get a hint for the trigger value. This page refreshes itself every few seconds.

Pre Trigger Start

Pre Trigger Start can be adjusted to prevent a cut off when audio should be sent earlier than detected. It defines the amount of time that will be streamed before the actual trigger occurred. This feature is most likely used in combination with the send on level feature.

Post Trigger Play

Post Trigger Play can be adjusted to prevent a cut off when audio should be sent longer than detected. It defines the amount of time that the device will continue streaming after the actual trigger has been cleared. This feature is most likely used with the send on level feature.

Buffer Underrun Mode (TCP)

The Buffer Underrun Mode (TCP) defines the action if a TCP stream is slower than the real stream from the encoder. In this case the output streaming buffer underruns and cannot hold older data any more. The device can then “disconnect” the TCP connection or it can “skip” the stream directly to the encoder stream without disconnecting TCP.

Streaming Strategy

The Streaming Strategy defines how a packet is build and sent. On “lowest latency” the encoded data will be sent directly after the encoding. On “optimal package” the packet will be filled up before sending.

UDP Tx Source Port

This setting is only used with a custom software application. Enter the used source port number for a UDP stream (between 0 and 65535). When set to 0 the source port is set to the same port as selected in the destination port (in section Stream to). If destination is set to “origin source” the UDP Receiver Port is used.

Sync Port

This parameter should only be changed if you use a firewall and have to use a fixed port. Enter the used port number for the sync stream (between 0 and 65535). When set to 0 the port is calculated by an algorithm.

Radio Path

Enter a radio path to listen to the transmitted stream of this Barix Instreamer using a device that is able to play MP3 radio stations (also PC software like WinAmp). The URL to connect is `http://x.x.x.x/p` where `x.x.x.x` is the IP address of this device and `/p` is this Radio path.

Example: `http://192.168.0.24/xstream`

The device can serve up to 6 concurrent radio streams.

icy-url / SIP user

“icy-url” is taken into account only for Shoutcast. Enter URL of web of your radio station (up to 60 characters). Example: “`http://www.exampleradio.com`” Default setting is empty.

SIP user is the user name that will be called on the target SIP device (SIP server or SIP phone) Example: “`betty`” calls “`betty@192.168.2.21`”

icy-genre

Genre of streamed music (icy-genre header). Taken into account only for connection when “Shoutcast source stream” type is selected. Default setting is empty .

Shoutcast stream

Select if the stream is private or public (icy-public header). Taken into account only for connection with Shoutcast source stream type selected. Default setting is “public”.

Stream to

There are up to 8 destinations to stream to. Each one can be directed to a device, or a multi- or broadcast address (destination connection types) or be set up as a listener waiting for a connection to be initiated by the other side (listener connection types). Each entry has its own IP address and Port. See the following sections on how to set the “Stream to” entries.

“Stream to” Considerations

The choice of settings to distribute the stream to other devices depends on your environment and desired functionality.

If the stream should be received guaranteed by only a few devices (up to 8) “raw TCP” can be used since lost packets are retransmitted automatically. If you encounter to many audio blanks (hick ups) then we recommend to

use RTP as lost packets are made up by the “Streaming client” firmware in the receiving “Exstreamer” device. This type is to be favored when the stream has to pass a number of routers (WAN or Internet) as RTP takes care of the sequence of received packets.

If the stream is intended to be received by many devices we recommend to use UDP broadcast as long as all devices are on the LAN as broadcast is not be able to pass over a WAN.

If your receivers are behind routers using NAT (network address translation) we recommend to use BRTP which can use port 80 and no change to the router is required. Only the router on the “Instreamer” side has to have an open port 80 forwarding requests to the “Instreamer”.

If your network infrastructure is capable of multicasting use multicast (instead of multiple unicasts) to reduce the traffic generated.

A mix of all the above is possible as each of the 8 destinations allow the individual choice of the connection type (except for the types “BRTP” and “SIP” which are only available with the first entry).

Stream to “Disabled” entry

Set the connection type to “not used” to disable an entry. The IP and Port can be left as is as they are as they do not matter on a disabled entry.

Stream to “Internet Radio” entry

Set the connection type to “Internet Radio” radio server for a single client (default). The IP “0.0.0.0” will act as a TCP listener (HTTP) waiting for a connection on the port selected under “Port#” (0=80). See also section [Radio Path](#) for additional configuration details.

Limitation: Even though eight entries can be configured only six concurrent radio servers are supported.

Stream to “RTP” entry

Set the connection type to “RTP” (Real Time Protocol) for an RTP destination. The IP “0.0.0.0” will broadcast (UDP) on the subnet (e.g. “192.168.0.255”) on the port selected under “Port#” (e.g. 4040), enter an IP for a UDP unicast destination (e.g. “192.168.0.11”).

Stream to “BRTP” entry

Set the connection type to “BRTP” (Barix Real Time Protocol) for a BRTP server (up to 32 clients). The IP “0.0.0.0” will act as a BRTP listener (UDP) waiting for BRTP clients requesting a stream on the port selected under “Port#” (e.g. 80).

Stream to “SIP” entry

SIP is only available with the first entry.
Set the connection type to “SIP” for an asterisk SIP server destination. Enter the IP of the SIP server. SIP works only when either “u-Law 8kHz” or “a-Law 8kHz” encoding is selected. Enter the UDP port of the SIP server under “Port#” (Port 0=5060).
See also section [icy-url / SIP user](#) further above.

Stream to “Raw UDP” entry

Set the connection type to “Raw UDP” for an UDP destination. The IP “0.0.0.0” will broadcast (UDP) on the subnet (e.g. “192.168.0.255”) on the port selected under “Port#” (0=3030), enter an IP for a UDP unicast destination (e.g. “192.168.0.11”).

Stream to “Raw TCP” entry

Set the connection type to “Raw TCP” for a single TCP client. The IP “0.0.0.0” will act as a TCP listener waiting for a connection on the port selected under “Port#” (0=2020).

Stream to “Icecast source” entry

Set the connection type to “Icecast source” to connect (TCP) to a single Icecast server. Enter IP and port of the Icecast server for the device to act as an Icecast source. When authentication is needed please read also section [Ice/Shoutcast](#) (Security settings).

Stream to “Icecast / ID3 source” entry

Set the connection type to “Icecast / ID3 source” to connect (TCP) to a single Icecast server expecting ID3 tags. Enter IP and port of the Icecast server for the device to act as an Icecast source with ID3 tags. In the current version the tags are static only. When authentication is needed please read also section [Ice/Shoutcast](#) (Security settings).

Stream to “Shoutcast source” entry

Set the connection type to “Shoutcast source” to connect (TCP) to a single Shoutcast server. Enter IP and port of the Shoutcast server for the device to act as a Shoutcast source. When authentication is needed please read also section [Ice/Shoutcast](#) (Security settings). The IP “0.0.0.0” will let the Instreamer act as a Shoutcast server itself waiting for a connection on the port selected under “Port#”. The function is then limited to a single client (a media player like Winamp) and only one entry is allowed to be set to Shoutcast server (IP 0.0.0.0).

SNMP settings

SNMP settings are located in the streaming section and are for advanced users only. Different SNMP traps can be generated depending on the state of the Barix Instreamer. The traps are triggered according to specific audio values as following:

Trap Target IP Address

Enter the IP address of the SNMP trap destination.

Low Audio Level

Define the low audio level for the trap generation. A trap will be generated as soon as the audio level goes below this value (and the “Silence timeout” has run out).

High Audio Level

Define the high audio level for the trap generation. A trap will be generated as soon as the audio level goes above this value.

Trap Repeat

Define the repeat interval for the SNMP trap sending. The trap will be repeated if the values are still according to the defined trap stages after this repeat time.

Silence Timeout

Define the time that has to run out before a trap is sent when the audio level is below the defined low audio value.

3.4 I/O Settings

Configure which command should be issued when the CTS signal on the serial connector is activated (see further below for commands).

SETTINGS						
NETWORK	AUDIO	STREAMING	I/O	CONTROL	SERIAL	SECURITY
CTS close command	<input type="text" value="c=91"/>					
CTS open command	<input type="text" value="c=84"/>					
<input type="button" value="Apply"/> <input type="button" value="Cancel"/>						

CTS close command

Configures which command should be issued when the CTS signal on the serial connector is activated (see further below for commands).

CTS open command

Configures which command should be issued when the CTS signal on the serial connector is deactivated (see further below for commands).

Commands

Commands can be joined using the “&” character and will be executed sequentially. For further commands refer to the “Instreamer technical documentation”.

SENDING MODE

c=84 : Deactivate the sending mode

c=91 : Activate the sending mode

SERIAL

c=89 : Simulate the CTS Signal being activated

c=90 : Simulate the CTS Signal being deactivated

c=60 : Activate the RTS Signal

c=61 : Deactivate the RTS Signal

3.5 Control settings

These settings adjust the control port properties.

The screenshot shows a window titled "SETTINGS" with a tabbed interface. The "CONTROL" tab is selected. It contains three input fields: "UDP command port" with the value "12301", "TCP command port" with the value "12302", and "Web server port" with the value "0". At the bottom of the window are two buttons: "Apply" and "Cancel".

UDP command port

Defines the port where the device will receive commands via UDP. To disable set this port number to “0”.

TCP command port

Defines the port where the device will receive commands via TCP. To disable set this port number to “0”.

Web server port

Defines the port on which the web server of the Barix Instreamer can be reached. If set to "0" the default HTTP port 80 is used.

3.6 Serial settings

These settings adjust the serial port, local port and serial gateway properties.

SETTINGS

NETWORK
AUDIO
STREAMING
I/O
CONTROL
SERIAL
SECURITY

RS-232

Baud rate

Data bits

Parity

Stop bits

Flow control

Local port

Destination IP . . .

Destination port

Baud rate

Select the serial transmission speed from “300” to “115200” Baud (bits per second).

Data bits

Select “7” or “8” data bits.

Parity

Select “no”, “even” or “odd” parity.

Stop bits

Select “1” or “2” stop bits.

Flow control

Select the type of flow control: “none”, “Software (XON/XOFF)” or “Hardware (RTS/CTS)”.

Local port

Defines the port on which the serial port can be accessed for serial gateway application. Only when “Local port” is set to "0" the serial port can be used as a command interface.

If the active serial gateway is enabled and the "Local port" is set to a value then this will be the source port of the TCP connection. On "0" a random source port is used.

Destination IP

To have this device actively establish a serial gateway select the destination IP address to the device where the serial data will be transmitted to (and received from). Select "0.0.0.0" when the serial port is used only locally.

Destination port

Defines the port for the active serial gateway function (see destination IP).

Notes: Both settings, "Destination IP" and "Destination port" have to be set to enable the gateway function.

When Serial Gateway is activated the serial port cannot be used as a command interface. This also applies for the device on the other side of the "Serial Gateway".

To establish a "Serial Gateway" between two devices only one device has to be activated. In other words: Only one device will need a Gateway destination IP and Port set. The other side will only need the parameter “Local port” to be set to the same value as the above “Destination port”. On power up the active device will connect to the selected device and will try to reconnect automatically in case of a lost connection. This allows you to establish a serial connection between the attached devices on each side over LAN or WAN.

3.7 Security settings

These settings can be used to secure the access to the device on different levels. The status is shown next to each password (set or not set). Access is free for levels without a password (default setting).

SETTINGS						
NETWORK	AUDIO	STREAMING	IO	CONTROL	SERIAL	SECURITY
Level	Password	Status				
Telnet/Serial Configuration	<input type="text"/>	not set				
Save Configuration	<input type="text"/>	not set				
View Configuration	<input type="text"/>	not set				
Control/Command	<input type="text"/>	not set				
4 (User)	<input type="text"/>	not set				
5 (User)	<input type="text"/>	not set				
6 (User)	<input type="text"/>	not set				
Ice/Shoutcast	<input type="text"/>	not set				
Listening	<input type="text" value="not protected"/>	<input type="button" value="v"/>				
SNMP Community RWrite	<input type="text" value="not protected"/>	<input type="button" value="v"/>				
SNMP Community Read	<input type="text" value="not protected"/>	<input type="button" value="v"/>				
<input type="button" value="Apply"/>		<input type="button" value="Cancel"/>				

Telnet / Serial configuration

Enter up to 7 characters to secure the access to the [Telnet](#) and Serial configuration. Without a valid password the network configuration cannot be changed. Enter 8 characters to erase the current key.

Save configuration

Enter up to 24 characters to secure the saving of the device configuration (Clicking the “Apply” button). Without a valid password the device configuration cannot be saved! Enter 25 characters to erase the current key.

Save configuration password usage

When the password is set the user has to type in the password in the “Save Config Password field” before

hitting the “Apply” button.



Without a valid password a warning will be displayed and the changes will not be saved.




View configuration

Enter up to 24 characters to secure the viewing of the device configuration (Clicking the “Config” button). Without a valid password the device configuration cannot be viewed! Enter 25 characters to erase the current key.

View configuration password usage

When the password is set the user clicking on the “Config” button has to type in the password into the password field of the pop up window (the user name does not matter).



Only one user can log in at a time. Further connections will be refused while one user is logged in.

To log out click on the “Logout” link next to the

“HOME” icon in the menu bar.



Please hit your browser’s “Reload” button if the “Logout” link is not visible while logged in.

Control / Command

Enter up to 24 characters to secure the access to all control and command interfaces (WEB/CGI, Serial, TCP and UDP). Without a valid password the device cannot be controlled. Enter 25 characters to erase the current key.

Note : This security option should be used very carefully and is intended for advanced users only. Since the CGI commands used in the web interface do not make use of passwords, setting this password would disable any control of the device using a browser.

Level 4 to 6 (User)

Enter up to 24 characters to secure the access to customized web pages in 3 levels. Intended for advanced users only, for details see the “Instreamer Technical Documentation”. Without a valid password these user web pages cannot be viewed. Enter 25 characters to erase the current key.

Ice/Shoutcast

Enter up to 24 characters for Icecast or Shoutcast server authentication. This password is only used when one or more “Stream to” entries are set either to “Icecast source”, “Icecast / ID3 source” or “Shoutcast source”. Enter 25 characters to erase the current key.

Listening

Choose which level is used for preventing unauthorized listeners from listening to Instreamer in Internet Radio mode, or "not protected" for access for all.

SNMP Community RWrite

Choose a password for the Read and Write Community, or "not protected" to ignore both the read and write communities or "no write access"

SNMP Community Read


Choose a password for the Read Community, or "not protected" to ignore the read community or "no access"
Note that the Community RWrite setting takes priority. This means that if the Community RWrite is set to not protected, Community Read is ignored.

4 Reverting to factory defaults

Click the **CONFIGURATION** button.


Click on the **DEFAULTS** button to enter the defaults page.

You will see the following screen:




Click on “Factory defaults” to revert all settings except “Network configuration” to factory defaults.

While restarting the device the following screen appears showing a number counting down:



Upon start up the following screen appears stating the successful reverting to factory defaults:



Hard default settings

To revert all settings (including the network settings) to factory defaults the “Reset” button has to be pressed for about 5 seconds while the Barix Instreamer is powered.

Note: Use this method if a connection to the Barix Instreamer cannot be established.

This can happen if you once have set a Static IP address, switched off “SonicIP” and then forgotten the IP address. The Hard default settings sets the IP Address to automatic discovery (0.0.0.0) and enables SonicIP.

If this fails we recommend to download the “Instreamer Rescue Kit” from www.barix.com.


Unzip the Kit and read “readme1st.txt” for instructions. This Rescue Kit reloads the entire firmware, resets the device to factory default settings using the supplied serial cable and a PC running Windows 2000, Windows XP or Linux.

5 Rebooting the device

Click the **CONFIGURATION** button.

Click on the **REBOOT** button to enter the reboot page.

You will see the following screen:




Click “Reboot the device” to restart the Barix Instreamer.

While restarting the device the following screen appears showing a number counting down:



Upon start up the following screen appears stating the successful restart:



6 Updating the device

Barix preloads all Instreamer family devices with firmware which is current at the day of production.

Barix constantly enhances the capabilities and functions and recommends to keep the firmware on the Barix Instreamer up-to-date.

Barix recommends the use of the “Serial Rescue” method to update the firmware.

For the alternative method “Web Update” the “Web server port” has to be set to “0” or “80” to work properly (0 will set the default port “80”).

If the web update is interrupted during the process (power or network loss) the device might become unreachable. In that case the “Serial Rescue” procedure is the only remedy. Please keep that in mind when planning a remote update.

6.1 Downloading the latest firmware

To download the latest “Instreamer” firmware version please visit www.barix.com.

- In the menu on the left side click on “**downloads**”
- In the center column select select the appropriate device (Instreamer or Instreamer 100) and click on the name of the device.
- Click in the section “**Firmware**” on the “Instreamer Update Kit” link to download it.
- Save the ZIP file and unpack it to a local drive.

Read the “_readme1st.txt” file for detailed instructions.

6.2 Serial Rescue

The “Serial Rescue” procedure loads the entire firmware and resets the device to factory default settings (current configuration is overwritten).

It is therefore helpful to note the current setting. Printing out the “status” page is the quickest way as the page contains all configuration parameters.

Open your web browser and type in the IP address of the Barix device in the URL field followed by “/status” and hit the “Enter” key.

- Example: “192.168.0.12/status”

To apply the Rescue using the supplied serial cross cable and a PC running Windows 2000, Windows XP or Linux follow the steps in the “_readme1st.txt” carefully as there are several different applications (batch files) to be started depending on the Barix hardware (new or legacy) and the PCs COM port number used.

Calculate approximately 2 minutes to complete the “Serial Rescue” procedure. After a successful rescue the device is ready for configuration according to your needs (see chapter [3 Device Configuration](#)).

6.3 Web Update

To apply the “Web Update” procedure you will need a standard web browser and the IP address of the device (announced by the [SonicIP](#) feature).

Make sure that the “Web server port” is set to “80” before starting the procedure.

Calculate approximately 2 minutes to complete the “Web Update” procedure.

STEP 1

Open your web browser

STEP 2

Type in the IP address of the Barix device and press Enter

- Example: “192.168.0.12”

STEP 3

Click the **CONFIGURATION** button.

STEP 4

Click on the **UPDATE** button to enter the update page.

You will see the following screen:

UPDATE

Please read the help instructions on the right side first.

Before you click the link below note that the update process can only be canceled by power cycling the device.

Clicking the back button in your browser will produce invalid content.

[Please click here to continue](#)

STEP 5

Click on “Please click here to continue” to launch the update process. The device will restart in a special mode called “Boot loader” and the following screen appears showing a number counting down from 4 to 0.

The device is restarting now. Please wait.

4


Please click [here](#) after the countdown if your browser doesn't support forwarding.

Upon start up the following screen appears:



STEP 6

Click on "Browse..." to select the file you want to update.




The file is named **compound.bin** located in the folder “update_rescue”.

Select the file and click on the “Open” button.

STEP 7

Attention: If you load the wrong file the device will not work and the “Serial Rescue Procedure” must be applied!



Update Barix Bootloader V99.09 Jun 2 2006

Resource


[Advanced Update](#)

Click on “Upload” to start the upload process which will take approximately 2 minutes.

Warning:

If the web update is interrupted during the process (power or network loss) the device might become unreachable. In that case the “Serial Rescue” procedure is the only remedy. Please keep that in mind when planning a remote update.

After a successful upload the following window appears:




compound.bin successfully loaded.


Click on [update](#) before updating the next component or unplug the power supply to reboot the device.

STEP 8

Click on the update link and then click on the "Reboot" button in the following window:




If you do not see the “Reboot” button then click the “Browse” button.



Select the file “reboot” and click on the “Open” button and in the following window click the “Upload” button.

The following screen appears:

**STEP 9**

After the device has rebooted click on the “here” link to reload the main page.

The device is now ready for configuration according to

your needs (see chapter [3 Device Configuration](#)).

Note: The “Web Update” procedure does not change the current configuration. Barix recommends nevertheless checking for correct parameters in the configuration as well as to set parameters for newly added features.

If you observe strange behavior after an update Barix recommends resetting the configuration to factory defaults by keeping the Reset button pressed until the red LED starts blinking (approx. 10 seconds) and to start over with the configuration of the device.

7 Dictionary

DHCP	Short for Dynamic Host Configuration Protocol, a protocol used to assign an IP address to a device connected to a Network.
IP	Short for Internet Protocol, the IP is an address of a computer or other network device on a network using IP or TCP/IP. Every device on an IP-based network requires an IP address to identify its location or address on the network. Example: 192.168.2.10
IPzator	Barix IPzator™ technology is designed for the purpose that the Barix device can create its own IP address according to the network structure in case it can't receive one from your network. If DHCP , AUTOIP or BOOTP fail, IPzator will create an IP address within the subnet and test it. If the address works and is not being used by another device on the network, it will give the address to the Barix device.
MAC address	Abbreviation for Medium Access Control, a MAC is a unique address number formatted in hexadecimal format and given to each computer and/or network device on a computer network. Because a MAC address is a unique address a computer network will not have the same MAC address assigned to more than one computer or network device. Example: A1:B2:C3:D4:E5:F6
Netmask	A number used to identify a sub network so that an IP address can be shared on a LAN (Local Area Network). A mask is used to determine what subnet an IP address belongs to. An IP address has two components, the network address and the host address. For example, consider the IP address 150.215.17.009. Assuming this is part of a Class B network, the first two numbers (150.2) represent the Class B network address, and the second two numbers (.017.009) identify a particular host on this network. The Netmask would then be 255.255.0.0 .
Ping	Ping is a basic Internet program that lets you verify that a particular IP address exists and can accept requests. Example: ping 192.168.2.10

- SonicIP** Barix SonicIP® technology is designed to vocally announce the Barix devices current IP address. This makes it easier and faster to obtain the necessary network information. To make use of SonicIP plug in the included earphone into RCA audio out, connect the network and plug in the power supply. It will announce the address over the earphones right after power up.
- Static IP** A Static IP is a fixed IP address that you assign manually to a device on the network. It remains valid until you disable it.
- Telnet** Telnet is a user command and an underlying TCP/IP protocol for accessing remote computers. On the Web, HTTP and FTP protocols allow you to request specific files from remote computers, but not to actually be logged on as a user of that computer. With Telnet, you log on as a regular user with whatever privileges you may have been granted to the specific application and data on that computer. Example: telnet 192.168.2.10

8 Legal Information

© 2007 Barix AG, Zurich, Switzerland.

All rights reserved.

All information is subject to change without notice.

All mentioned trademarks belong to their respective owners and are used for reference only.

Barix, Exstreamer, Instreamer, SonicIP and IPzator are trademarks of Barix AG, Switzerland and are registered in certain countries.

For information about our devices and the latest version of this manual please visit www.barix.com.



Barix AG
Seefeldstrasse 303
8008 Zurich

SWITZERLAND

Phone: +41 43 433 22 11
Fax: +41 44 274 28 49

Internet

web: www.barix.com

email: sales@barix.com

support: support@barix.com