

BARIX

Exstreamer Store&Play: FW update via USB

Updating an *Exstreamer Store&Play* via USB is only possible with devices from Production Week **PW: 32/14** onwards as written in the label under the device

Preparing the “update USB” stick:

1. **Download** and unzip the Firmware update image file (compound.img) from www.barix.com/downloads
Note: Registered login credentials are required for downloading
2. Copy the file (**compound.img**) to the root folder of an empty USB

Updating the *Exstreamer Store&Play* with the “update USB” stick:

3. **Remove the power** from the *Exstreamer Store&Play*
4. **Disconnect the Ethernet cable** from the *Exstreamer Store&Play*
5. **Insert** the “update USB” to the “EXT.” slot in front of the device
6. While **pressing and holding** the “RESET” button, **power up** the device
7. **Stop pressing** the “RESET” button after a couple of seconds of powering up
8. While updating, **both “STATUS” LEDs** (red and green) **will be lit**
Note: This operation can take 2 to 3 minutes
9. After updating, the device will **reboot** itself (blinking red “STATUS” LED)
10. Operation will resume normally with the new FW version already installed (solid green “STATUS” LED)
11. **Remove** the “update USB”
12. Reinsert the original USB (if any) and **re-connect the Ethernet cable**

DO NOT POWER OFF OR REBOOT THE DEVICE WHILE UPDATING

IMPORTANT NOTE: Updating to v1.6x requires to “[Reset Factory Defaults](#)” pressing the RESET button for 10 seconds until red LED starts to blink. ATTENTION because this will reset all Network and Fallback Config Server Settings. Finally “[Reboot](#)” the device (from the web UI’s REBOOT tab or with a short press of the RESET button) to restart the application from scratch.

Questions? Read the latest Store&Play User Manual or ask support@barix.com