



# IR REMOTE CONTROL KIT

## Quick Install Guide Version 1.2

### Infared remote control set for Barix audio devices

#### Package contents

- a IR remote control
- b Batteries (2 x AAA)
- c IR receiver for RS-232 port
- d This quick install guide


#### Support

For support please contact your local dealer or visit [www.barix.com](http://www.barix.com).

© Barix AG 4/2009, all rights reserved. All information is subject to change without notice. All mentioned trademarks belong to their respective owners and are used for reference only. Barix, Exstreamer and SonicIP are trademarks of Barix AG, Switzerland, and are registered in certain countries.



# Installation



## STEP 1

Insert the batteries (b) into the battery compartment located on the underside of the remote control (a). Make sure to check the signs of polarity and insert them correctly.

## STEP 2

Take the IR receiver (c) and plug the cable into the RS-232 connector of your Barix device.

## STEP 3

Consult the user manual (of the firmware currently loaded into your Barix device) to configure the used source of IR commands. Some devices come with an internal IR receiver which is enabled by default and must be changed from “Built-in” or “IR IN” to “Serial Dongle”.

## STEP 4

After configuring your device you can check the reception of IR commands by aiming at the receiver (c) with your IR remote control (a) and pushing any button. A flickering LED on the receiver shows the reception of an IR command. Read the firmware user manual for more information about the supported functions of the IR remote control.

For information about our products, manuals, technical documentations please visit [www.barix.com](http://www.barix.com).

Barix AG  
Seefeldstrasse 303  
8008 Zürich  
SWITZERLAND

[www.barix.com](http://www.barix.com)

