



## Barix Application Note ANI03 – Loading of Crestron specific application into a Barix Annunicom I00.

### Introduction:

This document details the steps required to upload the Crestron specific application into a Barix Annunicom I00 using the web update method.

### Procedure:

1. First obtain the file crestron\_yyyymmdd.zip from the Barix website, and then extract the application using a tool such as WinZIP. This will create a folder 'Crestron', containing a file 'compound.bin'.
2. Access the Annunicom's web UI, by typing its IP address into the URL field of your browser and pressing <ENTER>.
3. Click on the UPDATE button to enter the update page.
4. Click on "Please click here to continue" to launch the update process. The device will restart in a special mode called Bootloader, showing a number counting down

(4-3-2-1).

The following screen appears when the device is ready for the update process:

**Update** Barix Bootloader V99.12 Sep 19 2008

---

Resource

---

[Advanced Update](#)

5. To update the device with the application, click on "Browse" to locate the file that you want to upload; for this integration this is the file 'compound.bin', located in the Crestron folder.

6. Once the file has been selected, click on "Upload" to start the transfer of the file to the device. This can take a few minutes.

After a successful upload click on the "update" link and when the Update window reappears click the "Reboot" button. If there is no button, click on Browse and select the "reboot". The device will reboot with the new application.

7. Press and hold the Annunicom's Reset button for approximately 10s, to restore factory defaults. The device is now loaded and ready for configuration.